Aloe Premium Creamy Dish Soap Degreaser

Unleash the Ultimate Cleaning Performance with Aloe Premium Creamy Dish Soap Degreaser. Infused with aloe essence, this potent formula cuts through grease, leaving your dishes gleaming and refreshed.

Item	Ingredient	Wt%
1	Water	76.2
	INNOVALOE ALOE VERA GEL CONCENTRATE 10:1	2.0
2	Glycerin	0.3
3	Calcium carbonate	3.5
4	Sodium carbonate	4.5
6	Sodium alkylbenzene sulfonate	12.0
7	Sodium sulfate	0.5
8	Fragance	0.8
9	Dye	0.2



- 1. Heat the water to 70-80 °C and add the aloe vera concentrate.
- 2. Get the mix at 50 60 °C and add ingredients 3 to 7 in the order listed slowly with constant mixing.
- 3. Mix well after each ingredient has been added until the batch is clear.
- 4. Add dye or fragrance if wanted.
- 5. Mix well after all ingredients have been added, until a clear, smooth and homogenous batch is obtained that is free of lumps or particles then let cool at room temperature.

Call us! We will glady assist you at:

(+52-871) 750 0846

REGISTRATION. In addition, AMB has not undertaken a comprehensive patent search on the formulation. Suggestions of uses should not be taken as inducements to infringe any particular patent.