Aloe Hydrating Facial Mask for Intense Moisture and Nourishment

Dive into deep hydration and nourishment with our Aloe O/W-Facial Mask. Infused with aloe and an oil-in-water emulsion, this mask delivers intense moisture to quench your skin's thirst.

| Item | Ingredient | Wt% |
|------|--|------|
| 1 | Water | 59.8 |
| 2 | INNOVALOE AVG CONCENTRATE 10:1 | 2.0 |
| 3 | Triceteareth-4 Phosphate | 1.0 |
| 4 | PEG-4 Polyglyceryl-2 Stearate | 5.0 |
| 5 | Polysorbate 80 | 1.0 |
| 6 | Cetylstearyl Alcohol | 4.0 |
| 7 | Panthenol | 0.5 |
| 8 | Mineral Oil | 4.0 |
| 9 | Octyldodecanol | 10.0 |
| 10 | Bisabolol | 0.5 |
| 11 | Kaolin | 4.0 |
| 12 | Carbomer | 0.5 |
| 13 | Sodium Hydroxide Solution (10% in water) | 0.5 |
| 14 | Sodium Cocoyl Glutamate | 4.0 |
| 15 | Allantoin | 0.15 |
| 16 | Aloe Barbadensis Leaf Juice | 2.0 |
| 17 | Propylene glycol | 0.5 |
| 18 | Methyl paraben | 0.5 |
| 19 | Fragrance (Perfume) | 0.05 |



Procedure

- 1. Heat the water between 40 50 °C, add the aloe vera and begin mixing for 5 minutes.
- 2. Keeping the temperature between 50 60 °C add slowly the ingredients 3 to 16 with fast mixing while agitation and a pause between each ingredient until is dissolved to mix the next one.
- 3. Mix the batch until smooth and grump free.
- 4. Cold to 30 40 °C and add the perfume and conservatives (Propylene glycol and methyl paraben)
- 5. Continue mixing and let cool.

*DISCLAIMEE

einformation contained herein is being furnished for informational purposes only, upon the express condition that the User makes its own assessment of the appropriate use of such information. While the information contained herein is believed to be reliable, no presentations, guarantees or warranties of any kind are made as to its accuracy, suitability for a particular application or the results to be obtained herefrom. Agromayal Botanica SA de CV. ("AMB") cannot guarantee how any products associated with this formation will perform in combination with other substances or in User's process. Due to the variations in methods, conditions and equipment used commercially in processing these materials, no warranties or guarantees are made as to the suitability of the formation/products for the applications disclosed. AMB shall not be liable and the User assumes all risk and responsibility for, any use or handling of any material beyond AMB's direct control. AMB WELLINESS MAKES NO WARRANTIES, EXPRESS OR INPULED, ICLIDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. It is the User's sole responsibility to determine if there are any issues relating to patent infringement of any component or combination of moments relating to the supplied information. Nothing contained herein is to be considered as permission, recommendation, nor as an inducement to practice any patented invention without the permission of the patent owner. This suggested formulation is based are reliable, but it has not been subjected to extensive testing for performance, efficacy or safety. BEFORE DAMMERCIALIZATION, YOU SHOULD THOROUGHLY TEST THE FORMULATION OR ANY VARIATION OF IT TO DETERMINE ITS PERFORMANCE, EFFICACY AND SAFETY. IT IS YOUR RESPONSIBILITY TO OBTAIN ANY NECESSARY GOVERNMENT CLEARANCE, LICENSE OR SAFETY. IT IS YOUR RESPONSIBILITY TO OBTAIN ANY NECESSARY GOVERNMENT CLEARANCE, LICENSE OR SAFETY. IT IS YOUR RESPONSIBILITY TO OBTAIN ANY NECESSARY GOVERNMENT CLEARANCE, LICENSE OR SAFETY.





