

Aloe Facial Hydrating Mask with Polyquaternium for Deep Moisture

Indulge your skin with deep hydration using our Aloe Facial Mask with Polyquaternium. Infused with aloe and advanced moisture-locking Polyquaternium, this mask replenishes moisture levels, leaving your skin plump, smooth, and intensely hydrated.

Item	Ingredient	Wt%
1	Deionized Water	63.6
2	<u>INNOALOE AVG CONCENTRATE 10:1</u>	2.0
3	Disodium EDTA	0.2
4	Xanthan Gum	0.8
5	Glycereth-26	5.0
6	Glyceryl Stearate	4.0
7	Jojoba oil	1.5
8	Almond oil	4.0
9	Cetyl alcohol	3.0
10	Kaolin	12.0
11	Polyquaternium-24	2.8
12	Propylene glycol	0.55
13	Methyl paraben	0.55



Procedure

1. Heat the water between 40 – 50 °C, add the aloe vera and begin mixing for 5 minutes.
2. Keeping the temperature between 50 – 60 °C add slowly the ingredients 3 to 10 with fast mixing while agitation and a pause between each ingredient.
3. Mix the batch until smooth and grump free.
4. Cold to 30 – 40 °C and add the polymer (Polyquaternium-24) and conservatives (Propylene glycol and methyl paraben)
5. Continue mixing and let cool.

*DISCLAIMER

The information contained herein is being furnished for informational purposes only, upon the express condition that the User makes its own assessment of the appropriate use of such information. While the information contained herein is believed to be reliable, no representations, guarantees or warranties of any kind are made as to its accuracy, suitability for a particular application or the results to be obtained herefrom. Agromayal Botanica SA de CV. ("AMB") cannot guarantee how any products associated with this information will perform in combination with other substances or in User's process. Due to the variations in methods, conditions and equipment used commercially in processing these materials, no warranties or guarantees are made as to the suitability of the information/products for the applications disclosed. AMB shall not be liable and the User assumes all risk and responsibility for, any use or handling of any material beyond AMB's direct control. AMB WELLNESS MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. It is the User's sole responsibility to determine if there are any issues relating to patent infringement of any component or combination of components relating to the supplied information. Nothing contained herein is to be considered as permission, recommendation, nor as an inducement to practice any patented invention without the permission of the patent owner. This suggested formulation is only a representative formulation and it is not a commercialized product. AMB WELLNESS believes that the information and data on which this formulation is based are reliable, but it has not been subjected to extensive testing for performance, efficacy or safety. BEFORE COMMERCIALIZATION, YOU SHOULD THOROUGHLY TEST THE FORMULATION OR ANY VARIATION OF IT TO DETERMINE ITS PERFORMANCE, EFFICACY AND SAFETY. IT IS YOUR RESPONSIBILITY TO OBTAIN ANY NECESSARY GOVERNMENT CLEARANCE, LICENSE OR REGISTRATION. In addition, AMB has not undertaken a comprehensive patent search on the formulation. Suggestions of uses should not be taken as inducements to infringe any particular patent.