Aloe Lift Skin Tightening Facial Mask

Elevate your skincare routine with Aloe Lift Skin Tightening Facial Mask. Crafted with a potent blend of aloe vera and skin-firming ingredients, this mask works to tighten and lift, reducing the appearance of fine lines and promoting a more youthful complexion. Experience the revitalizing power of aloe as it reveals a firmer, toned, and beautifully uplifted skin.

Item	Ingredient	Wt%
1	Water	60.4
2	INNOVALOE AVG CONCENTRATE 10:1	2.0
3	Disodium EDTA	0.1
4	Glycerin	4.0
5	Ammonium Laureth sulfate	2.0
6	Triethanolamine	1.0
7	Pistachio vera seed oil	1.5
8	Jojoba oil	0.5
9	Glyceril Stereate	1.5
10	Titanium dioxide	5.0
11	Bentonite	3.0 5.0
12	Kaolin	
13 14	Carbomer, 2%	10.0 3.0
	Cetearyl Alcohol	
15 13	Propylene glycol	0.5 0.5
13	Methyl paraben	0.5



Procedure

- 1. Heat the water between 50 60 °C, add the aloe vera and begin mixing for 5 minutes.
- 2. Keeping the temperature between 65 70 °C add slowly the ingredients 3 to 14 with fast mixing while agitation and a pause between each ingredient until is dissolved to mix the next one.
- 3. Mix the batch until smooth and grump free.
- 4. Cold to 30 40 °C and add the perfume and conservatives (Propylene glycol and methyl paraben)
- 5. Continue mixing and let cool.

*DISCLAIME

te information contained herein is being furnished for informational purposes only, upon the express condition that the User makes its own assessment of the appropriate use of such information. While the information contained herein is believed to be reliable, no presentations, guarantees or warranties of any kind are made as to its accuracy, suitability for a particular application or the results to be obtained herefrom. Agromayal Botanica SA de CV. ("AMB") cannot guarantee how any products associated with this formation/products for the applications with other substances or in User's process. Due to the variations in methods, conditions and equipment used commercially in processing these materials, no warranties or guarantees are made as to the suitability of the formation/products for the applications disclosed. AMB shall not be liable and the User assumes all risk and responsibility for, any use or handling of any material beyond AMB's direct control. AMB WELLINESS MAKES NO WARRANTIES, EXPRESS OR IMPLIED, CLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. It is the User's sole responsibility to determine if there are any issues relating to patent infringement of any component or combination of monomerous processes of the patent owner. This suggested formulation is only representative formulation and it is not a commercialized product. AMB WELLINESS believes that the information and data on which this formulation is based are reliable, but it has not been subjected to extensive testing for performance, efficacy or safety. BEFORE DAMMERCIALIZATION, YOU SHOULD THOROUGHLY TEST THE FORMULATION OR ANY VARIATION OF IT TO DETERMINE ITS PERFORMANCE, EFFICACY AND SAFETY. IT IS YOUR RESPONSIBILITY TO OBTAIN ANY NECESSARY GOVERNMENT CLEARANCE, LICENSE OR INTERPRESSED AND ASPETY. IT IS YOUR RESPONSIBILITY TO OBTAIN ANY NECESSARY GOVERNMENT CLEARANCE, LICENSE OR INTERPRESSED ASSESSED A





