Aloe Vera Hydra Glow Moisturizing Lotion

Experience the ultimate hydration our Aloe Vera Moisturizing Lotion. Enriched with the moisturizing properties of aloe vera, this lotion deeply nourishes and replenishes your skin, leaving it supple, soft, and glowing. Embrace the rejuvenating power of HydraGlow and unveil skin that radiates with health and vitality.

Item	Ingredient	Wt%
Α	Oil phase Cetyl Palmitate	3.0
	Glyceryl Stearate (and) PEG-100 Stearate	2.5
	Triisostearin	1.0
	Cetyl Alcohol	2.0
	Mineral Oil	5.6
	Water phase Innovaloe Aloe juice single strength 1X	80.0
	Glycerin	3.0
	Methylparaben	1.0
	Propylparaben	1.0
	Colorant(s)	0.2
	Other components	
	Xanthan Gum	0.2
	Fragrance	0.5



Procedure:

Heat oil and water phases separately to 75-80 °C, mixing to homogeneity. Slowly add the water phase to the oil phase at high shear, mixing to unifor- mity (but at least fifteen minutes). When uniform, start cooling with moderate agitation. When cooled to 50 °C, add the remaining ingredients in order. When uniform and at the desired filling temperature stop cooling and mixing.

*DISCLAIMER

le information contained herein is being furnished for informational purposes only, upon the express condition that the User makes its own assessment of the appropriate use of such information. While the information contained herein is believed to be reliable, no presentations, guarantees or warranties of any kind are made as to its accuracy, suitability for a particular application or the results to be obtained herefrom. Agromances and the commercially in the commercially in processing these materials, no warranties or guarantees are made as to the suitability of the formation will perform in combination with other substances or in User's process. Due to the variations in methods, conditions and equipment used commercially in processing these materials, no warranties or guarantees are made as to the suitability of the processing these materials, no warranties or guarantees are made as to the suitability of the supplications disclosed. AMB shall not be liable and the User assumes all risk and responsibility for, any use or handling of any material beyond AMB's direct control. AMB WELLLNESS MAKES NO WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. It is the User's sole responsibility to determine if there are suspensed prelating to paterial supplication. Nothing contained herein is to be considered as permission, recommendation, nor as an inducement to practice any patented invention without the permission of the patent owner. This suggested formulation is based are reliable, but it has not been subjected to extensive testing for performance, efficacy or performance or per







