Aloe Revive Enhanced Liquid Laundry Detergent B

Revitalize your laundry routine with Aloe Revive Enhanced Liquid Laundry Detergent B. Crafted with the goodness of Aloe Vera, this upgraded formula ensures fresher and brighter garments.

Item	Ingredient	Wt%
1	Deionized Water	44.6
2	INNOVALOE ALOE VERA GEL CONCENTRATE 20:1	1.0
3	Sodium Chloride	2.2
4	Methylglycinediacetic acid Trilon® M Liquid	2.5
5	Ethanol	3.0
6	Propylene Glycol	3.5
7	Alcohol Alkoxylate	3.0
8	Proprietary Surfactant Blend, Dehypound® HDL 90	31.6
9	Borax	1.4
10	Calcium Chloride	0.1
11	Lauryl/Myristyl Glucoside,	2.8
12	Disteryl Biphenyl Derivative, Tinopal® CBS-X 4	0.1
13	Monoethanolamine	0.5
14	Kathon	0.1
15	Protease	1.25
16	Dye	0.35



Procedure:

While heating the water to 75-80°C, mix water with Aloe vera gel concentrate 10X, and then slowly add the ingredients 3 to 9 to the water agitated at maximum available shear. Mix until fully hydrated. Add the remaining ingredients in order and mix until uniform. Cool the mix at room temperature.

*DISCLAIMER

The information contained herein is being furnished for informational purposes only, upon the express condition that the User makes its own assessment of the appropriate use of such information. While the information contained herein is believed to be reliable, no representations, guarantees or warranties of any kind are made as to its accuracy, suitability for a particular application or the results to be obtained herefrom. Agromayal Botanica SA de CV. ("AMB") cannot guarantee how any products associated with this information will perform in combination with other substances or in User's process. Due to the variations in methods, conditions and equipment used commercially in processing these materials, no warranties or guarantees are made as to the sustainability of the information, products for the applications disclosed. AMB shall not be liable and the User assumes all risk and responsibility for, any use or handling of any material beyond AMB's direct control. AMB WELLINESS MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. It is the User's sole responsibility to determine if there are any issues relating to patent infringement of any components relating to the supplied information. Nothing contained herein is to be considered as permission, recommendation, nor as an inducement to practice any patented invention without the permission of the patent owner. This suggested in sonity are representative formulation and it is not a commercialized product. AMB WELLNESS believes that the information and data on which this formulation is based are reliable, but it has not been subjected to extensive testing for performance, efficacy or safety. BEFORE COMMERCIALIZATION, YOU SHOULD THOROUGHLY TEST THE FORMULATION OR ANY VARIATION OF IT TO DETERMINE ITS PERFORMANCE, EFFICACY AND SAFETY. IT IS YOUR RESPONSIBILITY O OBTAIN ANY NECESSARY GOVERNMENT CLEARANCE, LICENSE OR REGISTRATION, AND A particular appraisable and apprais





