

## Aloe Care Color-Safe Laundry Elixir

Embrace care and protection with Aloe Care Color-Safe Laundry Elixir. Powered by Aloe Vera, this gentle detergent safeguards your colors, keeping them vibrant and fresh.

Item	Ingredient	Wt%
1	Deionized Water	71.80
2	<b><u>INNOALOE ALOE VERA GEL CONCENTRATE 20:1</u></b>	1.00
3	Sodium Citrate	2.50
4	Dodecylbenzene Sulfonic Acid, Bio-Soft® S-101	3.50
5	(98 wt% TS)	
6	C12-15 Pareth-7, Tomadol® 25-7 (3) (100 wt% TS)	2.50
7	Sodium Laureth Sulfate (1 mole), Sulfochem™ ES-1	10.00
8	Surfactant (25% wt% TS) (*)	
9	Sodium Hydroxide (50%)	1.50
10	Triethanolamine	1.50
11	Noverite™ K-752 Polymer (62 wt% TS)	1.60
12	Polyvinylpyrrolidone, Kollidon® K-30 (100 wt% TS)	1.00
13	Novethix™ L-10 Polymer (30 wt% TS)	1.80
14	Neolone™ PE	0.80
15	Rain Fresh Fragrance	0.50



### Procedure:

1. Weigh deionized water into a mixing container. Mix Aloe Vera gel concentrate with water. Under medium agitation add sodium citrate. Wait until citrate is completely dissolved, then add Bio-Soft® D-101, Tomadol® 25-7 and Sulfochem™ ES-1 surfactant. Allow solution to mix 10-15 minutes, or until all surfactants are properly dispersed.
2. Add sodium hydroxide and triethanolamine. Let mix for 5-10 minutes.
3. Add Noverite™ K-752 polymer.
4. Add Kollidon® K-30 and mix until fully dissolved.
5. Add Novethix™ L-10 polymer. Let mix for 5-10 minutes.
6. Add preservative, fragrance and color.

### \*DISCLAIMER

The information contained herein is being furnished for informational purposes only, upon the express condition that the User makes its own assessment of the appropriate use of such information. While the information contained herein is believed to be reliable, no representations, guarantees or warranties of any kind are made as to its accuracy, suitability for a particular application or the results to be obtained herefrom. Agromayal Botanica SA de CV. ("AMB") cannot guarantee how any products associated with this information will perform in combination with other substances or in User's process. Due to the variations in methods, conditions and equipment used commercially in processing these materials, no warranties or guarantees are made as to the suitability of the information/products for the applications disclosed. AMB shall not be liable and the User assumes all risk and responsibility for, any use or handling of any material beyond AMB's direct control. AMB WELLNESS MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. It is the User's sole responsibility to determine if there are any issues relating to patent infringement of any component or combination of components relating to the supplied information. Nothing contained herein is to be considered as permission, recommendation, nor as an inducement to practice any patented invention without the permission of the patent owner. This suggested formulation is only a representative formulation and it is not a commercialized product. AMB WELLNESS believes that the information and data on which this formulation is based are reliable, but it has not been subjected to extensive testing for performance, efficacy or safety. BEFORE COMMERCIALIZATION, YOU SHOULD THOROUGHLY TEST THE FORMULATION OR ANY VARIATION OF IT TO DETERMINE ITS PERFORMANCE, EFFICACY AND SAFETY. IT IS YOUR RESPONSIBILITY TO OBTAIN ANY NECESSARY GOVERNMENT CLEARANCE, LICENSE OR REGISTRATION. In addition, AMB has not undertaken a comprehensive patent search on the formulation. Suggestions of uses should not be taken as inducements to infringe any particular patent.