## Aloe Scent Liquid Laundry Elixir with Fragrance Microcapsules A

Experience a scent sensation with Aloe Scent Liquid Laundry Elixir featuring Fragrance Microcapsules A. Powered by Aloe Vera, this detergent leaves your laundry irresistibly fresh all day long.

Item	Ingredient	Wt%
Α	Deionized Water	14.18
	<b>INNOVALOE ALOE VERA GEL CONCENTRATE 20:1</b>	1.0
	Laponite® RD	0.30
	Novethix™ HC200 Polymer (32%)	2.00
	Sodium Dodecylbenzenesulfonate, Bio-Soft®	38.00
	SDBS 30-HA (30%)	
	Sodium Laureth Sulfate, Zetesol® NL-2 U (28%)	12.00
В	Polyacrylic Acid Polymer, Noverite™ K-752 Polymer (63%)	1.60
	Sodium Hydroxide (18%)	3.00
С	C12-15 Pareth-7, Neodol® 25-7	7.50
	Potassium Cocoate (39%)	8.00
	Propylene Glycol	4.00
	Sodium Citrate	6.00
	Sodium Diethylenetriamine Pentamethylene	1.00
	Phosphonate, Dequest® 2066 (32%)	
	Benzisothiazolinone, Parmetol® D11	0.08
	Free Fragrance Oil	0.60
	Liquitint® Blue HP	0.02
	Liquitint® Pink AL	0.01
D	Fragrance microcapsules	0.30



## Procedure:

- 1. Add Aloe vera gel Concentrate to water, Disperse Laponite® RD into water and mix for 20 minutes at high speed. 2. Add Novethix™ HC200 polymer and mix for 20 minutes at high speed.
- 3. Add both anionic surfactants and mix for 15 minutes at high speed.
- 4. Add Part B ingredients and make sure that the pH stays around 8 at all times.
- 5. Add Part C ingredients and mix until homogenous (no lumps).
- 6. Add fragrance microcapsules with gentle mixing

The information contained herein is being furnished for informational purposes only, upon the express condition that the User makes its own assessment of the appropriate use of such information. While the information contained herein is believed to be reliable, no representations, guarantees or warranties of any kind are made as to its accuracy, suitability for a particular application or the results to be obtained herefrom. Agromayal Botanica SA de CV. ("AMB") cannot guarantee how any products associated with this information will perform in combination with other substances or in User's process. Due to the variations in methods, conditions and equipment used commercially in processing these materials, no warranties or guarantees are made as to the suitability of the INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, It is the User's sole responsibility to determine if there are any issues relating to patent infringement of any component or combination of a representative formulation and it is not a commercialized product. AMB WELLNESS believes that the information and data on which this formulation is based are reliable, but it has not been subjected to extensive testing for performance, efficacy or safety. BEFOR





