

## ALOE FACIAL CLEANSER LOTION FOR WIPES

Discover the soothing power of Aloe with our Facial Cleanser Lotion for Wipes. Formulated to cleanse and refresh, this Aloe-infused lotion brings gentle care to your skincare routine.

Item		Ingredient	Wt%
A	1	Deionized Water	86.95
	2	<u><a href="#">INNOVALOE ALOE VERA GEL CONCENTRATE 10:1</a></u>	2.00
	3	Acrylates/C10-30 Alkyl Acrylate Crosspolymer, Carbopol®* Ultrez 21 Polymer	0.45
	4	Phenoxyethanol, Methyl-, Ethyl-, Butyl-, Propyl-, (and) Isobutylparaben, Phenonip®	1.00,1.00,0.50
B	5	Isodecyl Neopentanoate, Schercemol™* 105 Ester	4.00
	6	Neopentyl Glycol Diethylhexanoate, Schercemol™* NGDO Ester	2.00
	7	Isostearyl Neopentanoate, Schercemol™* 185 Ester	1.00
	8	Ethylhexyl Hydroxystearate, Schercemol™* OHS Ester	1.00
	9	Acrylates/C10-30 Alkyl Acrylate Crosspolymer, Pemulen™* TR-2 Polymer (3)	0.20
C	10	Disodium Laureth Sulfosuccinate (40%), Chemccinate™* DSLS Surfactant	1.00
	11	Aminomethyl Propanol (95%), AMP-Ultra™ PC 2000 (4)	0.40



### Procedure :

1. PART A: Disperse Carbopol®\* Ultrez 21 Polymer by sprinkling on the surface of warm (25-45°C) deionized water. After polymer is wetted (no dry white powder visible), mix slowly at low speed.
2. Add Phenonip® to PART A.
3. Combine PART B ingredients in a separate vessel. Do not heat. First mix oil phase ingredients then disperse Pemulen™\* TR-2 Polymer. Mix until dispersion is uniform with no lumps.
4. With moderate agitation, add the PART B slurry to PART A. Mix for 10 - 20 minutes to allow polymers to swell.
5. Add Chemccinate™\* DSLS Surfactant and AMP-Ultra™ PC 2000 and mix vigorously to produce a smooth, white cream. Mix until uniform.

### \*DISCLAIMER

The information contained herein is being furnished for informational purposes only, upon the express condition that the User makes its own assessment of the appropriate use of such information. While the information contained herein is believed to be reliable, no representations, guarantees or warranties of any kind are made as to its accuracy, suitability for a particular application or the results to be obtained herefrom. Agromayal Botanica SA de CV. ("AMB") cannot guarantee how any products associated with this information will perform in combination with other substances or in User's process. Due to the variations in methods, conditions and equipment used commercially in processing these materials, no warranties or guarantees are made as to the suitability of the information/products for the applications disclosed. AMB shall not be liable and the User assumes all risk and responsibility for, any use or handling of any material beyond AMB's direct control. AMB WELLNESS MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. It is the User's sole responsibility to determine if there are any issues relating to patent infringement of any component or combination of components relating to the supplied information. Nothing contained herein is to be considered as permission, recommendation, nor as an inducement to practice any patented invention without the permission of the patent owner. This suggested formulation is only a representative formulation and it is not a commercialized product. AMB WELLNESS believes that the information and data on which this formulation is based are reliable, but it has not been subjected to extensive testing for performance, efficacy or safety. BEFORE COMMERCIALIZATION, YOU SHOULD THOROUGHLY TEST THE FORMULATION OR ANY VARIATION OF IT TO DETERMINE ITS PERFORMANCE, EFFICACY AND SAFETY. IT IS YOUR RESPONSIBILITY TO OBTAIN ANY NECESSARY GOVERNMENT CLEARANCE, LICENSE OR REGISTRATION. In addition, AMB has not undertaken a comprehensive patent search on the formulation. Suggestions of uses should not be taken as inducements to infringe any particular patent.