ALOE ENRICHING BABY WIPE LOTION

Embrace moments of cherishment with Aloe Cherish, an enriching cream that transforms ordinary wipes into moments of care. Enriched with aloe's nurturing properties, it's a treasure for your baby's skin.

Item	Ingredient	Wt%
А	Deionized water	38.03
	INNOVALOE ALOE VERA GEL CONCENTRATE 10:1	1.0
	Glycerin (Protameen)	5.00
В	Schercemol 1818 Ester (Lubrizol) (Isostearyl isostearate)	2.00
	Alpha-Bisabol Natural (Bisabol) (Symrise)	0.20
	Vitamin E Acetate (Protameen) (Tocopheryl acetate)	0.20
	Glucate DO Emulsifier (Lubirzol) (Methyl glucose dioleate)	0.20
	Pemulen TR-2 Polymer (Lubrizol) (Acrylates/C10-30	0.12
	alkyl acrylate crosspolymer)	
С	Sodium hydroxide (5%)	0.25
D	Plantacare 818 UP (Cognis) (Coco-glucoside (50%))	2.00
E	Euxyl PE 9010 (Schulke & Mayr) (Phenoxyethanol (and)	0.50,0.50
	ethylhexylglycerin	
F	Deionized water	50.00



Procedure:

Phase A mix Aloe vera gel concentrate with deionized water and then mix glycerin . Phase B--add ingredients 3-6 in a separate vessel. Disperse Pemulen TR2 Polymer into oil phase. Add phase B to phase A. Mix for 20-30 minutes to allow the polymer to swell. Neutralize batch with sodium hydroxide (5%). Mix vigorously until uniform. Add coco-glucoside. Mix slowly to avoid air entrapment. Add preservative (phase E). Mix until uniform. Dilute with deionized water. Mix until uniform. PROPERTIES: Appearance--thin white lotion; pH--5.8-6.2; Viscosity (mPa.s) (Brookfield RVT @ 20 rpm, 25[degrees]C, #2 spindle, measured after 24 hours)--400-700; Stability--passed 3 months @ 45[degrees]C and RT, Passed 5 cycles freeze/thaw. COMMENTS: This formula has not been tested on any nonwoven substrate, but is a suggested starting point formulation to help meet difficult viscosity and emulsion stability criteria. Preservation and stability may be dependent on the nonwoven substrate that is used for application.

*DISCLAIMER

The information contained herein is being furnished for informational purposes only, upon the express condition that the User makes its own assessment of the appropriate use of such information. While the information contained herein is believed to be reliable, no representations, guarantees or warranties of any kind are made as to its accuracy, suitability for a particular application or the results to be obtained herefrom. Agromayal Botanica SA de CV. ("AMB") cannot guarantee how any products associated with this information will perform in combination with other substances or in User's process. Due to the variations in methods, conditions and equipment used commercialls, no warranties or guarantees are made as to the use the variations in methods, conditions and equipment used commercialls, no warranties or guarantees are made as to the variations in methods, conditions and equipment used commercialls, no warranties or guarantees are made as to the variations in methods, conditions and equipment used commercialls, no warranties or guarantees are made as to the variations in methods, conditions and equipment used commercially of the applications disclosed. AMB shall not be liable and the User assumes all risk and responsibility for, any use or handling of any material beyond AMB's direct control. AMB WELLNESS MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. It is the User's sole responsibility to determine if there are any issues relating to patent information. Nothing contained herein is to be considered as permission, nor as an inducement to paratice any patented information of the patent owner. This suggested formulation is only a representative formulation and it is not a commercialized product. AMB WELLNESS believes that the information and data on which this formulation is based are reliable, but it has not been subjected to extensive testing for performance, efficacy or safety. BEFORE MARNES CLICENSE OR REGISTRATI



www.amb-wellness.com

