

ALOE GUM COMFORT MOUTHWASH

Experience soothing relief with Aloe Gum Comfort Mouthwash. Enriched with aloe vera, this mouthwash helps ease gum discomfort while promoting oral health and freshness.

Item	Ingredient	Wt%
A	Deionized Water	7.70
	Glycerin	10.00
	Sodium Saccharin	0.50
	Sodium Benzoate	0.50
	Sodium Fluoride	0.20
	Maltitol	7.00
	Sorbitol (Sol. 70%)	50.00
	Hydrated Silica Tixosil 43	8.00
B	Lactic Acid	0.05
C	Quillaja saponaria Extract+Aqua .Andean QD	8.00
D	Ultra (25% Aq. Sol.) Natural surfactant	
	<u>INNOALOE ALOE VERA GEL CONCENTRATE 10:1</u>	1.0
	Polysorbate 60/Tween 60	0.60
E	Aroma	1.00
	Ethanol	5.00



Procedure:

Preliminary phases

Prepare a 25% solution of Andean QD Ultra in deionised water under cupboard

Phase E: Mix the ingredients until clear solution;

Addition scheme

1) Add ingredients A in the main mixer and mix until clear solution after each addition. Then, add A1 and homogenize with turbine and blades under vacuum for 10', then heat the phase to 65°C under vacuum. At this temperature, homogenize with turbine and blades under vacuum for 10'. Sample and check homogeneity.

2) Add B and homogenize for 10'. Check homogeneity. Cool down to 35-40°C.

3) Add, in sequence, C, D and phase E and mix with blades under vacuum for 5' after each addition. Cool to RT. Take a sample for analytical controls.

*DISCLAIMER

The information contained herein is being furnished for informational purposes only, upon the express condition that the User makes its own assessment of the appropriate use of such information. While the information contained herein is believed to be reliable, no representations, guarantees or warranties of any kind are made as to its accuracy, suitability for a particular application or the results to be obtained herefrom. Agromayal Botanica SA de CV. ("AMB") cannot guarantee how any products associated with this information will perform in combination with other substances or in User's process. Due to the variations in methods, conditions and equipment used commercially in processing these materials, no warranties or guarantees are made as to the suitability of the information/products for the applications disclosed. AMB shall not be liable and the User assumes all risk and responsibility for, any use or handling of any material beyond AMB's direct control. AMB WELLNESS MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. It is the User's sole responsibility to determine if there are any issues relating to patent infringement of any component or combination of components relating to the supplied information. Nothing contained herein is to be considered as permission, recommendation, nor as an inducement to practice any patented invention without the permission of the patent owner. This suggested formulation is only a representative formulation and it is not a commercialized product. AMB WELLNESS believes that the information and data on which this formulation is based are reliable, but it has not been subjected to extensive testing for performance, efficacy or safety. BEFORE COMMERCIALIZATION, YOU SHOULD THOROUGHLY TEST THE FORMULATION OR ANY VARIATION OF IT TO DETERMINE ITS PERFORMANCE, EFFICACY AND SAFETY. IT IS YOUR RESPONSIBILITY TO OBTAIN ANY NECESSARY GOVERNMENT CLEARANCE, LICENSE OR REGISTRATION. In addition, AMB has not undertaken a comprehensive patent search on the formulation. Suggestions of uses should not be taken as inducements to infringe any particular patent.