ALOE PLAQUE DEFENSE TOOTHPASTE

Defend against plaque with Aloe Plaque Defense Toothpaste. Enriched with aloe vera, this toothpaste effectively fights plague buildup for a healthier smile.

Item	In gredient T	Wt%
Α	Deionized Water	23.00
	Aloe vera concentrate 10x	0.59
	Chondrus crispus Extract .Viscarin GP 209	1.00
	Deionized Water	5.00
	Sodium Saccharin	0.25
	Sodium Monofluorophosphate	0.76
	Sorbitol (Sol. 70%)	25.00
	PEG-8	4.00
В	Tetrasodium Pyrophosphate	1.75
	Tetrapotassium Pyrophosphate	1.75
	Hydrated Silica Tixosil 73	7.00
	Hydrated Silica Tixosil 43	7.00
	Silica Aerosil 200	1.00
	Sodium Bicarbonate	11.00
C	Sorbitol (Sol. 70%)	2.00
C	Titanium Dioxide. A310 Tudor Aspen	0.50
5	Demin. Water	4.50
D	INNOVALOE ALOE VERA GEL CONCENTRATE 10:1	0.50
	Quillaja saponaria Extract Andean QD Ultra Powder Natural	2.00
	surfactant	1.20
E	Aroma	0.20
	Triclosan . Irgasan DP 300	



Procedure:

Preliminary phases

Phase C: Mix the ingredients until homogeneous suspension;

Phase D: Mix the ingredients until clear solution under cupboard; excessive foam formation must be avoided.

Phase E: Mix the ingredients until clear solution;

Addition scheme

- 1) In main mixer, add Viscarin PC 209 to water and homogenize with turbine and blades, under vacuum, for 10', then heat the phase to 65°C, always under vacuum. At this tempera- ture, homogenize with turbine and blades under vacuum for 10'. Sample and check homogeneity.
- 2) In a side mixer add ingredients A1, mixing until clear solution after each addition.

 3) Add phase A1 to phase A and homogenize with turbine and blades for 10' while starting to cool to room temperature.
- 4) Add, in sequence, ingredients B and homogenize with turbine and blades for 10' after each addition. Check homogeneity of the phase after each addition. 5) Add, in sequence, phases C, D and E while mixing with blades under vacuum for 5' after each addition. Take a sample
- for analytical controls.

*DISCLAIMER

The information contained herein is being furnished for informational purposes only, upon the express condition that the User makes its own assessment of the appropriate use of such information. While the information contained herein is believed to be reliable, no representations, guarantees or warranties of any kind are made as to its accuracy, suitability for a particular application or the results to be obtained herefrom. Agromayal Botanica SA de CV. ("AMB") cannot guarantee how any products associated with this information will perform in combination with other substances or in User's process. Due to the variations in methods, conditions and equipment used commercially in processing these materials, no warranties or guarantees are made as to the suitability of the information/products for the applications disclosed. AMB shall not be liable and the User assumes all risk and responsibility for, any use or handling of any material beyond AMB's direct control. AMB WELLLNESS MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. It is the User's sole responsibility to determine if there are any issues relating to patent infringement of any component or combination of components relating to the supplied information. Nothing contained herein is to be considered as permission, recommendation, nor as an inducement to practice any patented invention without the permission of the patent owner. This suggested formulation is only a representative formulation and it is not a commercialized product. AMB WELLNESS believes that the information and data on which this formulation is based are reliable, but it has not been subjected to extensive testing for performance, efficacy or safety. BEFORI COMMERCIALIZATION, YOU SHOULD THOROUGHLY TEST THE FORMULATION OR ANY VARIATION OF IT TO DETERMINE ITS PERFORMANCE, EFFICACY AND SAFETY. IT IS YOUR RESPONSIBILITY TO OBTAIN ANY NECESSARY GOVERNMENT CLEARANCE, LICENSE OF







