## ALOE RADIANT SMILE TOOTHPASTE

Embrace a radiant smile with Aloe Radiant Smile Toothpaste. Aloe vera enhanced, this toothpaste helps maintain a bright and healthy-looking smile.

Item	In gredient	Wt%
1	Water	49.8
2	INNOVALOE AVG POWDER 200X	0.5
3	Octadecene Maleic Anhydride	6.0
4	copolymer hydrolyate (disodium salt)	1.3
5	Sodium hydroxide	0.4
6	Sodium lauroyl sarcosinate	0.3
7	Sodium saccharin	0.2
8	Sodium fluoride	0.2
9	Phosphoric acid	3.0
10	Hydroxyethylcellulose	6.0
11	Hydrated silica abrasive	
12	Sodium lauryl sulfate	1.2
13	Glycerin	23.0
14	Hydrated silica thickener	8.0
15	Methyl salicylate	0.1



## Procedure:

The water, copolymer, hydroxide and aloe vera get heated at 85°C and stirred for 45 min. to form the water-soluble or dispersible tubule blocking agent along with the aloe vera concentrate. The sarcosinate, saccharin, fluoride and acid were then stirred in. After cooling, the binder and abrasive were blended in under vacuum for 30 min. The lauryl sulfate, glycerin and thickener were then blended in, under vacuum, for another 30 min. Finally the flavor oil was blended in.

## \*DISCLAIMER

The information contained herein is being furnished for informational purposes only, upon the express condition that the User makes its own assessment of the appropriate use of such information. While the information contained herein is believed to be reliable, no representations, guarantees or warranties of any kind are made as as to its accuracy, suitability for a particular application or the results to be obtained herefrom. Agromayal Botanica SA de CV. ("ANAB") cannot guarantee here was not products associated with this information will perform in combination with other substances or in User's process. Due to the variations in methods, conditions and equipment used commercially in processing these materials, no warranties or guarantees are made as to the suitability of the information/products for the applications disclosed. AMB shall not be liable and the User assumes all risk and responsibility for, any use or handling of any material beyond AMB's direct control. AMB WELLINESS MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. It is the User's sole responsibility to determine if there are any issues relating to patent infringement of any components relating to the supplied information. Nothing contained herein is to be considered as permission, recommendation, nor as an inducement to practice any patented invention without the permission of the patent owner. This suggested in sold patent infringement of any components or combination of patent derivations of the patent owner. This suggested to extensive testing for performance, efficacy or safety. BEFORE COMMERCIALIZATION, YOU SHOULD THOROUGHLY TEST THE FORMULATION OR ANY VARIATION OF IT TO DETERMINE ITS PERFORMANCE, EFFICACY AND SAFETY. IT IS YOUR RESPONSIBILITY TO OBTAIN ANY NECESSARY GOVERNMENT CLEARANCE, LICENSE OR REGISTRATION and the patent of the patent o







